

Telescopic Glide Shelf Guides Accessories



910881

For range cooker with hybrid and gas ovens, this allows you to slide out the shelf fully and safely, very useful when taking baking out of the oven, or for checking or turning hot food. Simple to install, the action is smooth and easy.

Specifications

Features
